


## OPERATOR'S MANUAL

## SERVICE AND MAINTENANCE



Diesel Wiring Diagram