


HOOD AND INSTRUMENT PANEL



1265 TRACTOR AND 1270 TRACTOR - OLIVER
 Figure 158: HOOD AND INSTRUMENT PANEL

1	31-2900102	1	Panel (Alternate 677610A) (S/N 000001 -)
1	677610A	1	Panel (S/N 000001 -)
2	677620A	2	Cover (S/N 000001 -)
3	672079A	2	Pin (S/N 000001 -)
4	676099A	2	Pin (S/N 000001 -)
5	674460A	6	Pad (S/N 000001 -)
6	672708A	2	Pad (S/N 000001 -)
7	674396A	2	Handle (S/N 000001 -)
8	672650A	2	Lock Washer (S/N 000001 -)
9	672823A	2	Lock Washer (S/N 000001 -)
10	674386A	2	Lever (S/N 000001 -)
11	677621A	1	Side Panel - Center Right (S/N 000001 -)
12	672030A	7	Washer (S/N 000001 -)
13	672021A	6	Lock Washer (S/N 000001 -)
14	672408A	2	Nut (S/N 000001 -)
15	672379A	4	Screw (S/N 000001 -)
16	677611A	2	Bracket (S/N 000001 -)
17	677622A	1	Side Panel - Center Left (S/N 000001 -)
18	677607A	1	Lid - Upper (S/N 000001 -)
19	677631A	2	Screw (S/N 000001 -)
20	672019A	2	Lock Washer (S/N 000001 -)
20	31-2900249	2	Washer (S/N 000001 -)
21	677613A	2	Pad (S/N 000001 -)
22	672358A	8	Screw (S/N 000001 -)
23	672820A	14	Lock Washer (S/N 000001 -)
24	672826A	4	Cap Screw (S/N 000001 -)
25	677608A	1	Panel - Instrument (S/N 000001 -)
26	677618A	1	Cowl - Rear (S/N 000001 -)
27	677626A	1	Boot (S/N 000001 -)
28	670432A	6	Cap Screw (S/N 000001 -)
29	677628A	1	Liner (S/N 000001 -)
30	677619A	1	Panel - Rear (S/N 000001 -)
31	672054A	1	Pin (S/N 000001 -)
32	670580A	1	Spring (S/N 000001 -)
33	672241A	2	Lock Washer (S/N 000001 -)
34	677630A	2	Screw (S/N 000001 -)
35	677614A	1	Rod (S/N 000001 -)
36	672022A	4	Lock Washer (S/N 000001 -)
37	672360A	4	Cap Screw (S/N 000001 -)