





- 11 677179A cap
- rb 9966958
- rpls 72090620
- 12 31-2903431 radiator
- rb 72093204
- rpls 72090619, 30-3010910
- 14 677189A shroud
- 19 677182A bracket 2WD
- 19 31-2900330 bracket 4WD



- 1 676700A fan blade
- rb 72089485
- rpls R69800, 4593320
- 7 31-2902214 pulley
- 8 30-3045080 belt
- rb 72090561V
- rpls 72094519, 72090561
- 13 30-3014193 pulley
- rb 72089658
- 14 672226A nut
- 16 31-2900197 hub
- rb 72089645
- 17 31-2900034 key
- rb 72089643
- rpls 4655844
- 20 31-2902215 shield
- 21 31-2902438 fan
- 22 31-2902439 spacer





- 1 677214A hose
- 4 31-2902108 thermostat
- 5 677201A gasket
- 9 31-2900135 o-ring
- 10 31-2902109 pipe
- 11 31-2902106 gasket
- 15 72090472 water pump
- 17 677199A gasket

- 18 677210A pipe
- 20 677191A hose
- NOTE: 2 used without coolant heater
- 20 30-3182355 hose
- NOTE: used with coolant heater
- 20 156543A hose
- NOTE: used with coolant heater
- 22 30-3030105 pipe
- NOTE: used without coolant heater
- 22 155612A pipe
- NOTE: used with 30-3141748 coolant heater

- 24 31-2902107 deflector
- 25 677205A gasket
- 26 672197A screw
- 27 672363A screw
- 28 677198A gasket
- 29 677217A nut
- 30 677219A stud
- 31 672192A cap screw
- 32 31-2900629 support
- 33 31-2900630 plug
- 34 30-3030091 gasket
- 35 677192A valve
- NOTE: used without coolant heater
- 35 KS517 valve
- NOTE: used with coolant heater
- 30-3141748 coolant heater
- 30-3141756 cord
- 37 677197A valve
- 38 677193A boot
- 39 677194A sender
- 40 677215A gasket