


BREAKDOWN
DISTRIBUTOR

674 122-AS



02702

ISSUED 8-26-66

Item	Part Number	Qty	Description
	674122AS	1	Distributor
1		1	Housing (Order Complete Distributor)
10	674127A	1	Ring
30	671703A	1	Cup - Grease
45	671792A	1	Coupling
50	671706A	1	Pin
55	671795A	1	Spring
60	674141A		Washer (As Req'd)
65	671793A	1	Washer
100	674142AS	1	Shaft Asy. - Drive
105	674143A	1	Shaft
110	671796A	1	Washer
115	671699A	1	Washer
120	674128A	2	Weight
125	674129A	1	Ring
130	674130A	1	Plate
135	674131A	1	Spring
140	674132A	1	Spring
170	674133A	1	Cam
175	674134A	1	Screw
180	674135A	1	Washer
185	674136A	1	Felt
190	671765A	1	Washer
200	674137AS	1	Plate With Breaker Points
220	674138A	1	Plate
240	674139AS	1	Breaker Points With Insulator (671711-A)
255	671711A	1	Insulator
265	671698A	1	Retainer
270	674140A	1	Screw
290	674144A	1	Screw
300	674145A	1	Condenser
305	671814A	1	Screw
310	674548A	1	Washer
315	672185A	1	Lock Washer
350	671800A	1	Rotor
360	671777A	1	Cap
370	671778A	1	Carbon Brush
375	671696A	2	Spring
380	671779A	3	Screw
385	672185A	3	Lock Washer
430	674146A	1	Screw
435	671701A	2	Plate - Insulator
440	674147A	1	Block - Insulator
445	672028A	2	Washer
450	674148A	2	Nut
455	672186A	2	Lock Washer